





Blixer 4 #1

INDEX	REF.	DESIGNATION	Pricelist in : USD
1	BX3031	Lid W/Wiper Blade Assy.	
2	BX3031.1	Handle	
3	117656	(G) Bowl Lid (Blixer4)	
4	BX3031.3	Lid Seal (BX3)	
5	BX3031.5	Holder W/Veri. & Horiz. Wipe Blade	
6	BX3031.4	Horizontal Wipe Blade	
7	BX3029	*Blade (BX3)	
8	101556	(G) Blixer4 Bowl Only	
9	BX3069	(G) Blixer4 Bowl Only	
10	117766	(G) Shaft (Blixer4)	
11	117623	(G) Motor Ring (Blixer4)	
12	R118	Motor Support Seal	
13	104070	(G) Screw Cover (Blixer4)	
14	39206	(G) Motor Support Assy (Blixer4)	
15	103694	(G) Circuit Board (Blixer4)	
16	102913	(C) Button Block Retainer R300,R301U "C"	
17	102911	(C) PC Board Supp. R300,R301U Series "C"	
18	117703	(K)Control Board Retaining Pin	
19	104131	(G) PC Board Fuse/Protector (Blixer4)	
20	39207	(G) Switch Assy (Blixer4)	
21	407844	(G) Data Plate (Blixer4)	
22	29441	(C) Reed Switch, R300,R301U Series "C"	
23	R3009S	Relay 2cr3285 Steaky	
24	BX3031.2	Lid with seal	
25	BX3031.7	Holder W/Vertical Wiper	
26	BX3031.6	Vertical Wiper Blade	
27	104122	(G) Vent Cover (Blixer4)	
28	104078	(G) Motor Centering Ring (Blixer4)	
29	302036	(G) Motor (Blixer4)	
30	104113	(G) Baffle (Blixer4)	
31	R106	Bottom Cushion Bushing	
32	103761	(C) Screen R300,R301U Series C	
33	504277	(G) Power Cord (Blixer4)	
34	39201	(G) Base (Blixer4)	
35	R3001	Foot, Black	